

INVERSE HEAT CONDUCTION Ill-posed Problems

2nd Edition, WILEY, 2023

Keith A. Woodbury, Hamidreza Najafi, Filippo de Monte, James V. Beck

Heat conduction Matlab function for the X12B-0T0 case using a piecewise-linear approximation (pla): **fdX12B_0T0_pla.m**

Syntax

```
fdX12B_0T0_pla(xd, td, p, A, M)
```

Description

fdX12B_0T0_pla (xd , td , p , A , M) returns the dimensionless temperature Td at a given dimensionless location xd from the heated surface, between 0 and 1, and at a given dimensionless time td , when a time variation of the surface temperature having p as an exponent (only positive) is applied. Also, it calls the fdX12B20T0 (xd , td , $trefd$, A) building block function that is computed with an accuracy of 10^{-A} ($A = 2, 3, \dots, 15$), while M indicates the number of time steps chosen up to the dimensionless time td of interest.

If xd and td are not single values but arrays ($\text{length}(xd) = m$ and $\text{length}(td) = n$) defining the dimensionless locations and times of interest, respectively, the above function returns the dimensionless temperature Td as a double (2D) subscripted array, where $\text{size}(Td) = [m, n]$.

Examples

Example 1

```
>> Td=fdX12B_0T0_pla(.1, .1, 2, 3, 10)
```

```
Td =
```

```
0.006145733624194
```

Example 2

```
>> fdX12B_0T0_pla(.1, .1, 2, 3, 1000)
```

```
ans =  
0.006131431786859
```

Example 3

```
>> xd=[0.1 0.5 0.7]'
```

```
xd =  
0.10000000000000000  
0.50000000000000000  
0.70000000000000000
```

```
>> td=[0.01 0.2]'
```

```
td =  
0.01000000000000000  
0.20000000000000000
```

```
>> Td=fdX12B_0T0_pla(xd,td,3,5,100)
```

```
Td =  
0.000000143601870 0.005308357922621  
0.0000000000002447 0.000900251585158  
0.0000000000000001 0.000349945983513
```